YUFUIN RIKYU : Climate & AC Controller Guide

Daikin Wall-Mounted Multi-Zone Climate Console : English Reference

Property: Yufuin Rikyu (1839-1 Yufuincho Kawakami, Yufu, Oita 879-5102)

1. START / STOP (Top Right Button): Press once to activate or turn off climate control.
2. SWITCH OPERATION MODE (Top Left Button): Cycle between Cooling, Heating, Dry, and Fan.
3. TEMPERATURE UP / DOWN (Center Top & Bottom Buttons): Adjust target room temperature (18C to 30C).
4. AIR BLOWING STRENGTH / DIRECTION (Bottom Left Button): Adjust airflow speed and louver angle.
5. MENU / CONFIRM (Center Circle Button): Enter advanced timer or louver settings.
6. CANCEL (Bottom Right Button): Return to standard display screen.

Chashitsu (Tea Room) Note:

Traditional rooms feature independent climate controls with identical mode icons.

Kindly switch off climate units upon final departure at 11:00.