YUFUIN RIKYU : Restroom Heated Bidet & Flush Guide

TOTO Wall-Mounted Washlet Control Panel : English Reference

Property: Yufuin Rikyu (1839-1 Yufuincho Kawakami, Yufu, Oita 879-5102)

1. STOP (Top Row, Far Left Square Button): Halts all active cleansing or drying functions.
2. REAR / SOFT CLEANSING (Top Row, Second Button): Standard or gentle posterior warm water wash.
3. FRONT / WIDE BIDET (Top Row, Third Button): Feminine front wash and wide-spray mode.
4. WARM AIR DRYER (Top Row, Fourth Button): Gentle warm air drying cycle.
5. WATER PRESSURE [- / +] (Bottom Row): Decreases (-) or increases (+) spray intensity.
6. WAND POSITION [Up / Down] (Bottom Row): Adjusts nozzle position forward or backward.
7. CLEAN WAND / DEODORIZE (Bottom Left): Activates self-cleaning wand rinse or air deodorizer.
8. FLUSH CONTROLS: Select Full Flush (Large Kanji) or Eco Flush (Small Kanji) on the upper wall unit.