YUFUIN RIKYU : Underfloor Heating Reference

Noritz RC-D804C N30 Floor Heating Controller : English Lid Translation

Property: Yufuin Rikyu (1839-1 Yufuincho Kawakami, Yufu, Oita 879-5102)

1. MAIN POWER (Bottom Right Button on Outer Cover): Press to turn floor heating ON (green LED).
2. TEMPERATURE LEVEL (Inside Lid, Right Up/Down Arrows): Adjust floor warmth from Level 1 (Low) to 9 (Hig
3. ECO / MODERATE MODE (Center Black Button): Reduces floor temperature slightly after prolonged operatio
4. TIMER ON / OFF (Top Right Black Button Inside Lid): Activates programmed Timer 1 or Timer 2.
5. EARLY OFF FUNCTION (Bottom Left): Automatically turns off heating 30 minutes prior to timer end.

Safety & Comfort Precaution:

Please refrain from lying directly on the heated floor for extended periods to prevent low-temperature skin irritation. The indicator lamp remains illuminated briefly after shutoff.